

RIOTFENCE™

ASSEMBLY INSTRUCTIONS

- Unpack and separate enclosed frame from section of fence.
- Construct frame horizontally (i.e. laying on ground) using cord guided assembly- fitting all parts of frame securely in place.
- Place top of fence over partially assembled frame using the 3 chains attachments to designate top frame (white slats should be on top).
- Proceed to attach fence using all chains and tightly securing them to frame with quick links (*side chains can later be used for multiple unit linkage).
- Attach bungee cords, top and bottom first. Side bungees can be attached when unit is upright, after portals are customized.
- While still laid on ground, attach front foot stabilizing frame with 45-degree angle braces using the enclosed wing nuts and bolts.
- Upright unit with 45-degree brace should facing toward crowd.
- Connect 2 remaining foot frame stabilizers (no brace).
- Make portal customized adjustments at this time then connect remaining bungees.

Additional Information

The barrier can be modified to create portals by cutting and shifting, or removing plastic inserts. Various configurations can be developed for user's individual preference for observation or for counter measure delivery. For additional information see website www.riotfence.us or email Dan Sr. at darbywire@aol.com with any technical questions.



©2017 RiotFence™ is a registered trademark of Mobile Defense Systems LLC & Edward J. Darby & Son Inc.
1-800-875-6374 – www.riotfence.us – sales@riotfence.us

Rev. 4/13/2013